



**STEP 1**  
ELECTRICAL CONNECTION




**STEP 2**  
INSERT THE RETROFIT HOUSING




**STEP 3**  
COMBINE THE MODULE


Step 3-A:  
ALIGN THE FOUR HOLES.




Step 3-B:  
ROTATE THE HEAT SINK.




Step 3-C:  
THE MODULE LOCKED WITH A CLICK.




Step 3-D:  
USE TOOL TO FASTEN  
SCREW AT THE BOTTOM  
OF THE BODY.




**STEP 4**  
LENS




Step 4-A  
ALIGN THE MODULE  
AND LENS




Step 4-B  
TURN IN A "CLOCKWISE" DIRECTION  
TO MOUNT THE LENS TO MODULE




**STEP 5**  
ELECTRICAL CONNECTION




Step 5-A  
CONNECT MALE & FEMALE  
QUICK CONNECTOR



Step 5-B  
INSERT QUICK CONNECTOR  
INTO BASE





Step 5-C  
LOCKED WITH A CLICK.




## STEP 6

### FIX WITH CLIPS


PUT THE LIGHT INTO THE CEILING AND USE CLIPS TO FIX THE HOLES ON THE LIGHT. PUT THE CLIPS INTO THE HOLES.




**Step 6-A**  
PLACE THE CLIP AT THE  
BOTTOM OF THE HOLE.




**Step 6-B**  
PUSH THE CLIP INTO THE  
HOLE.



**Step 6-C**  
USE SCREWDRIVER TO  
ADJUST THE HEIGHT OF THE  
CLIP.



**Step 6-D**  
USE SCREWDRIVER TO TURN IN  
A "CLOCKWISE" DIRECTION TO  
LOWER THE CLIP AND SECURE TO  
THE CEILING.





SELECT APPROPRIATE HOLE ACCORDONY TO CEILING THICKNESS.

## STEP 7

### REFLECTOR


#### Step 7-A

CLAMP THE REFLECTOR CLIP.



#### Step 7-B

INSERT THE REFLECTOR CLIP INTO  
HOLES ON SIDE OF MODULE.



#### Step 7-C

PUSH INTO CEILING TO COMPLETE THE INSTALLATION.

